

# WALL<sup>®</sup> HDD ホルダー

WALL INTERIOR TV STAND

## 組立説明書 (第1版)

この度は、お買い上げいただき誠にありがとうございました。  
この商品を末永く、安全にお使いいただくために、  
この「組立説明書」をよく読み正しくご使用ください。  
また、これらを必要に応じて見られるよう、大切に保管してください。

### 免責事項

- ・本製品または本製品の一部の誤使用や誤用に起因するいかなる損害や負傷について、当社は一切の責任を負いません。
- ・当社は、間接的損害や派生的損害についても一切責任を負いません。



注意

- ・本製品には、飲み込むと窒息する恐れのある小さな部品が含まれています。
- ・本製品の組み立ては、お子様の手の届かないところで実施してください。

- ・以下の場合、当社はいかなる損害賠償の責任も負いません。

- 1) お客様が本製品を第三者に転売または再販された場合。
- 2) 不注意や不適切な取り扱いによる故障や破損の場合。
- 3) 他の製品との組合せにより生じた故障及び損傷の場合。
- 4) 天災、火災、環境破壊、有害物質、戦争、異常電圧、外部要因による故障または損傷の場合。
- 5) 本来の目的以外の用途に使用された場合。

この商品は日本の株式会社ナカムラの企画・品質管理によって中国（原産国）で製造しました。  
品質向上の為に改良に伴い一部仕様が異なる場合があります。

販売元 株式会社ナカムラ  
〒145-0065 東京都大田区東雪谷 4-20-10

公式ブランドサイト <https://equals.tokyo/>

製品についてのお問い合わせ

[info@equals.tokyo](mailto:info@equals.tokyo)

お問い合わせフォーム



# WALL<sup>®</sup> HDD ホルダー

WALL INTERIOR TV STAND

品 番	D05000267
種 類	HDD ホルダー
サ イ ズ	W19 D6.5 H17 cm
材 質	スチール
表 面 加 工	粉体塗装
重 量	0.3kg
原 産 国	中国
耐 荷 重	1.5kg

## 注意

- 本製品の取り付け時に、HDD の電源コードや USB ケーブルを抜き差しする場合は、HDD の動作が止まっていることを確認してから行なってください。

## 注意

注意を無視した取扱いをすると、物質損害を被ったり、障害を負う可能性があります。

### 1 組立・設置の注意

#### 1-1. けが、破損の原因

取り付けの際は、ネジでしっかり固定する。

#### 1-2. 変色、破損の原因

屋内で使用する。直射日光や熱、冷暖房の風があたらない場所に置く。

### 2 使用の注意

#### 2-1. におい

開梱時、梱包材や塗料などのにおいが残っている場合は、固く絞った布でよく拭き、風通しのよいところへしばらく放置する。

### 3 お手入れの注意

#### 3-1. ひび割れや変色、変形の原因






表面を水気の多いぞうきんなどでふかない。

クレンザー、シンナー、ベンジン、アルコール、灯油などは使わない。(化学ぞうきんはその注意書きに従う)

※薄めた中性洗剤を浸した柔らかい布を固く絞って汚れを落とし、乾いた布で水分をよくふき取る。

※ねじは定期的に点検し、緩んでいるときはしっかり締める。(目安：1 カ月に 1 度)

## WALL V2 / V3 / V5 に取り付ける


Q	×	1	
R	×	1	
S	×	2	
T	×	1	 (小)
K	×	1	 (細)

スタンド本体付属部品



転倒防止ワイヤーと  
一緒に取り付けます。

Point



テレビに取り付けた 2 本のバーが  
中央にある場合


G	×	2	
---	---	---	---

HDD ホルダー付属部品








Ⓔ で動かなくなるまで  
締め付けます。

Point



## WALL V3sw に取り付ける

Q	×	1	
R	×	1	
S	×	2	
T	×	1	 (小)
K	×	1	 (細)


スタンド本体付属部品

V3sw の組立が  
左右首振りタイプの場合



転倒防止ワイヤーと  
一緒に取り付けます。


Point




V3sw の組立が  
壁寄せタイプの場合

G	×	2	
---	---	---	---

HDD ホルダー付属部品




## WALL V4 に取り付ける




HDD ホルダー付属部品


中央に取り付ける場合




左右に取り付ける場合




## WALL TV台用スタンドに取り付ける




HDD ホルダー付属部品



## WALL M1に取り付ける




HDD ホルダー付属部品



## WALL A2 に取り付ける



HDD ホルダー付属部品



# WALL<sup>®</sup> HDD HOLDER

WALL INTERIOR TV STAND

## Assembly Instructions [1st Edition]

Thank you for purchasing this product.

In order to use this product safely and for many years, please read this document carefully and use the product correctly.

Also, keep this in a safe place so that you can refer to it as needed.

## Please Note

- Nakamura Co. Ltd. assumes no responsibility for damage or injury of any kind because of the misuse or improper application of any part of this product in any way by any person.
- Nakamura Co. Ltd. shall not be liable for any indirect or consequential damages whatsoever.



**· THIS PRODUCT CONTAINS SMALL ITEMS THAT COULD BE A CHOKING HAZARD IF SWALLOWED.**  
**caution · KEEP ALL PRODUCTS OUT OF THE REACH OF CHILDREN WHILE ASSEMBLING.**

Nakamura Co. Ltd. shall not be responsible for any damages in the following cases:

- 1) When the customer resells the product to a third party.
- 2) In case of failure or damage due to careless or improper handling.
- 3) In case of failure or damage caused by use in combination with other products.
- 4) In case of natural disaster, fire, environmental destruction, harmful substances, war, abnormal voltage or malfunction or damage due to external factors.
- 5) If product is used for purposes other than the original purpose.

This product was manufactured in China (country of origin)  
under the planning and quality control of Nakamura Corporation of Japan.  
Some specifications may differ due to improvements for better quality.

---

Nakamura Co. Ltd.

Officail brand site : <https://equals.tokyo/>

Contact us in English : [info-gl@nakamura-jpn.co.jp](mailto:info-gl@nakamura-jpn.co.jp)


# WILL<sup>®</sup> HDD HOLDER

WALL INTERIOR TV STAND

<b>model number</b>	D05000267
<b>type</b>	HDD holder
<b>size</b>	W19 x D6.5 x H17cm
<b>material</b>	steel
<b>surface finish</b>	powder coating
<b>weight</b>	0.6 lbs / 0.3kg
<b>country of origin</b>	China
<b>maximum load</b>	6.6 lbs / 3kg

## **Caution**

When unplugging or plugging in the HDD power cord or USB cable during installation of this product, make sure that the HDD has stopped operating before doing so.

 **Caution** If the following precautions are not observed, injury or property damage may occur.

## **1 Assembly and installation**

### **1-1. Causes of injury and damage**

When installing, secure all parts firmly with screws.

### **1-2. Causes of discoloration and damage**

For indoor use. Keep away from direct sunlight, as well as direct airflow from heating or air conditioning.

## **2 During use**

### **Cause of odor**

When unpacking, there may be residual smells from packing materials or paint. Wipe well with a clean dry cloth and leave in a well-ventilated place for a while.

## **3 Care and maintenance**

### **Causes of cracking, discoloration and deformation**






Do not wipe the surface with a damp cloth.

Do not use cleanser, thinner, benzene, alcohol, kerosene, etc.


- Use a soft cloth soaked in a diluted neutral detergent, tightly wrung, to remove dirt and wipe off any residual moisture with a dry cloth.

- Check the screws regularly and tighten them securely if they are loose. (Once a month)

## Installation on WALLV2/V3/S1/V5


Q × 1	
R × 1	
S × 2	
T × 1	 (small)
K × 1	 (thin)

These are the accessory parts of TV stand.




Point


Attach it together with the screw hole to attach the fall prevention wire.



In case the two pcs of TV brackets are positioned  
**in the center**


G × 2	
-------------	---

This is the accessory part of HDD HOLDER








Point

Push to fix with (G)




## Installation on WALL V3sw

Q × 1	
R × 1	
S × 2	
T × 1	 (小)
K × 1	 (細)


These are the accessory parts of TV stand.

V3sw assembled as  
**Swivel type**



Point



Attach it together with the screw hole to attach the fall prevention wire.



V3sw assembled as  
**Non-swivel type**

G × 2	
-------------	---

This is the accessory part of HDD HOLDER





## Installation on WALL V4




G  
×  
2



This is the accessory part  
of HDD HOLDER

### Installation at the center

### Installation at the left or right





## Installation on WALL Stand for TV console

G  
×  
2



This is the accessory part  
of HDD HOLDER





## Installation on WALL M1

G  
×  
2



This is the accessory part  
of HDD HOLDER



## Installation on WALL A2

G  
×  
2



This is the accessory part  
of HDD HOLDER

